

PowerCell Easy Connect Fuel Pump Harness Kit



Please Read Carefully

Prior to Installation

- Use caution and always wear eye protection.
- Avoid skin contact with fuels and oils.
- If you don't feel confident installing this product, please seek professional assistance.

What's Included in your kit

- | | |
|----------------------------------|--------------------------|
| A) Easy Connect Harness | D) Dielectric Grease |
| B) 3M Adhesive Heat Shrink | E) 7" Heavy Duty Zip Tie |
| C) Stainless Strain Relief Clamp | |

*** Note:** the contents of your kit may vary depending on model and year

Installation Instructions

- Step 1) Remove the fuel tank and set it back on the frame so you can easily access the fuel pump connectors. This task is much easier to accomplish when the tank is empty
- Step 2) Insert one of the 3M heat shrink tubes over the fuel tank side of the new adaptor cable (this is the side without the screw nut) and connect the cable to the fuel pump harness on the fuel tank. Center the heat shrink over the assembled connector and using a heat gun, evenly heat the heat shrink (Figures 1&2)
- Step 3) Using an 8mm wrench, remove the left front bolt securing the fuel pump to the tank
- Step 4) Fit the included strain relief over the fuel pump harness and attach it to the pump using the bolt removed in Step 3. (Figure 3)
- Step 5) Insert the second section of 3M heat shrink over the remaining half of the adaptor cable and connect it to the motorcycle side of the fuel pump harness. Center the heat shrink over the assembled connector and shrink it to fit.
- Step 6) Feed the assembled harness over the lower frame rail and secure it in place using the supplied Zip Tie. (Figure 4)
- Step 7) Apply a small amount of dielectric grease to the contacts and connect the two halves of the new Easy Connect Cable... cycle the ignition to confirm that the fuel pump works properly. Re-install the fuel tank. Fin...

